

Instruction Manual



Insert the Spacer (A) replacing the old with a new o-ring.



Install the central Drum (B). Put the spring washer (C) and the nut (D) with the Medium Threadlocker. Close respecting the lock recomended by Ducati.



Insert the plates (E) following this sequence:

- Sintered plate; steel plate;
 Sintered plate; steel concave plate;
- 3. Sintered plate; steel plate;
- Sintered plate; steel concave plate;
- Sintered plate; steel plate;
- Sintered plate; steel plate 2mm;




Put the vented cover (F). Put the 6 screws and retainers (G,H). Close respecting the lock recommended by Ducati.

www.edovignaracing.com

Technical Sheet DRYCLTIDM Rev.01 -EN





	Kit		quantity	
Α	Basket		1	
В	Spacer		1	_
С	Complete Drum		1	
D	Washer		1	
E	Nut		1	
F	Set Plate		1	
G	Cover		1	
н	Springs (Not Included)		6	
J	Retainers		6	
K	Screw M5x25 (Not Included)		6	*
Tech	nnical Parameters	mm	Quantity	=

Screw M3x25 (Not iliciaded)		D	
Technical Parameters	mm	Quantity	
Set Plates Thickness (w/o fitted plate on central drum)	36,5		
Sintered Plate Thickness	2,5	9	
Steel Plate Thickness	1,5	5	
Steel Plate Thickness	2	1	
Steel Concave Plate Thickness	1,5	3	

Warning

- EVR CTS Slipper clutch KIT is built with technologies materials and treatments of the highest quality. We recommend that the installation is done by qualified technicians.
- EVR company disclaims any liability due to incorrect assembly of the component parts.
- Be sure that the product and the whole kit box are intact and complete.
- · Start always the operation in clean and suitable spaces and for the proper fitting you must use the necessary equipment and wear only specific and safety clothing.
- · Follow strictly these instructions.

FITTING ON A MOTORBIKE THIS PRODUCT, COULD AFFECT THE MOTORCYCLE TYPE APPROVAL AND COMPLIANCE WITH THE LEGAL REQUIREMENTS AND THUS LEAD THE OWNER OR USERS TO INFRINGE THE PREVAILING RULES OF THE LAW.

www.edovignaracing.com

Technical Sheet DRYFCLIDM Rev.01 -EN-