

MW headlight kit

This kit will update your Monster or Sport Classic with a more modern looking headlight lens.

Included in the kit is a 7 inch clear headlight, a billet adapter ring, and two posi-lock connectors. You will reuse your headlight outer ring and the spring clips that hold the lens in place.

1. Remove the outer ring by loosening the Phillips screw at the bottom.
2. The outer ring will come off with the headlight lens in it.
3. Disconnect the headlight from the plug and then move the running light.
4. Remove the spring clips and remove the factory headlight lens.
5. Set the new headlight into the adapter ring.
6. Using the image below bend the stock spring to a slight angle.
7. Install the modified springs to hold the new assembly into the stock outer ring.
8. Using the supplied posi-locks connect the running light to the factory wiring.
9. Install the new headlight assembly and check everything for proper function.





