

Installation Instructions

03-0204 SpeedyMoto Ducati 749/999 Triple Clamp

03-0221 SpeedyMoto Ducati 848/1098 Triple Clamp

Parts included

1. One very special SpeedyMoto triple clamp
2. One very special SpeedyMoto steering lock extension (Fitted with 40 mm bolt replace with 25 mm for 848)
3. Two stainless M8 x 20 mm & One M8 x 30 mm Allen head bolts (in bag with Blue Permatex Thread locker)
4. One 5 mm damper spacer & Two M6 x 25 stainless allen head bolts (also in bag) only in 03-0221 kit

Tools required

1. 6mm Allen wrench
2. 5mm Allen wrench
3. Dead-blow mallet
4. Torque wrench

Note:

Additional tools may be required to remove/reinstall your steering damper, depending on the make and model.



Installation

1. Remove your current steering damper, and top triple clamp.

Note:

While removing the steering damper mount, be careful not to lose any spacers/washers/o-rings as you remove the bolt.

2. Apply Permatex threadlocker to (Qty. 2) 20mm fork clamp bolts and install in Fork Clamps.
Apply Permatex threadlocker to (Qty. 1) 25mm steering stem bolt and install in Center Clamp.
3. Align and place your new triple into place.
4. Tap triple clamp evenly until the the clamp seats firmly on the steering stem.
5. Torque all 3 bolts to 14 Nm (~10.5 Ft. Lbs.)
6. Reinstall your steering damper mount using the stock damper spacers/washers/o-rings, making sure the o-ring and washer goes on in the correct order.
7. Use 5mm spacer and 6 x 25mm bolt (with threadlock) to attach damper to frame.
8. Ride it, and tell all your friends about SpeedyMoto!