

Ducati Clutch Slave Cylinder Installation instructions

Preparation: Before installing your new purchase please ensure you have at least the following items at hand: 4mm Allen Key, 5mm Allen Key, 14mm socket wrench, 11mm ring spanner, Flat screwdriver, a suitable catch vessel and 500ml+ of manufacturer's approved clutch fluid (Ensure you are 100% familiar with their instructions on use before commencing installation).

THESE INSTRUCTIONS ONLY APPLY WHEN THE MOTORCYCLE HAS THE ORIGINAL STOCK CLUTCH FITTED.

Included in the kit is an extension rod (pre 1999 Ducati models), and should be fitted if the pushrod length is less than 30mm from the crankcase face

Installing the slave cylinder

- 1.** Remove any fairing (where necessary) to ensure entire area is easily accessible. The bike will need to be held upright or slightly away from the side stand to assist the escape of air bubbles.
- 2.** Have a cloth wrapped around the existing clutch body when loosening (but not removing) the banjo bolt to minimise the spread of fluid. When loosening the bolt ensure your catch vessel is in place for any escaping fluid. Remove the existing cylinder from the engine keeping the clutch line and original cylinder together preferably completely wrapped in cloth.
- 3.** *Included in the kit is an extension rod (pre 1999 Ducati models), and should be fitted if the pushrod length is less than 30mm from the crankcase face* The clutch slave cylinder is pre-assembled and is ready to go straight on. However if the piston is removed at anytime then please ensure the seals are lubricated with clutch fluid when replacing the piston and ensure it is inserted all the way until it's 'home'. Ensure all surfaces are totally clean and dirt free.
- 4.** Once the new slave cylinder is attached to the bike (ensuring great care is taken when attaching) the slave cylinder can be completely filled with clutch fluid. The pipe and banjo bolt can be removed from the original cylinder and attached to the new one. Do this as quickly and safely as possible to curb later bleeding times. When attaching the banjo bolt to the new slave cylinder be also sure to use the copper washers provided to reseal the connection.
- 5.** Bleed the system through the original bleed valve at the top of the slave cylinder ensuring a pipe is attached and leading to the catch vessel. Apply approximately six pulls on the clutch lever (holding the lever in on the last stroke). Loosen the valve to release the fluid's pressure and tighten before releasing the lever. Repeat this until the clutch no longer feels 'spongy'. Also ensure the clutch reservoir levels do not drop low and draw in air.

Installation is complete and you may now enjoy the benefits of your new Oberon clutch slave cylinder. The clutch at first will feel 'loose' due to the increased efficiency but it won't take long to adjust to the effortless and smoothness of the new clutch system. You may also be rest assured that the cylinder itself also comes with a manufacturer's warranty. Refer to www.oberon-performance.co.uk for further details.

