

In order to install the Corse Dynamics damper bracket on your 2008-2010 Ducati 848 you must utilize an aftermarket top triple clamp or tap the stock triple clamp with a 6mm x 1.0 pitch tap to install the Ohlins damper as shown in the before and after picture below.

Before:



After:

