



Corse Dynamics Triple Clamp Torque Specs-

Top Clamp Bolts:

(Qty 3) – 14nm

Bottom Clamp Bolts:

(Qty 6) – 17nm

Steering Stop Bolts:

(Qty 2) – 14nm

Steering Bearings:

No number! Hand tight until they begin to bind, then back off a little. You want no binding (too tight), but no fore and aft play (too loose) either.