



Battery Cross Reference Chart (Rev. 7-4-2011)

YuPn	ShoStdRec	YB10L-A2	LFX14L2-BS12
12N10-3A-2	LFX09L2-BS12	YB10L-B	LFX14L2-BS12
12N11-3A-1	LFX09L2-BS12	YB10L-B2	LFX14L2-BS12
12N12A-4A-1	LFX09A2-BS12	YB12A-A	LFX14A2-BS12
12N14-3A	LFX14L2-BS12	YB12A-B	LFX14A2-BS12
12N24-3	LFX24L3-BS12	YB12AL-A	LFX14L2-BS12
12N5.5-3B	LFX07L2-BS12	YB12AL-A2	LFX14L2-BS12
12N5.5-4A	LFX07A2-BS12	YB12B-B2	LFX14A1-BS12
12N5-3B	LFX07L2-BS12	YB12C-A	LFX14A2-BS12
12N5-4B	LFX07L2-BS12	YB14-A2	LFX14A2-BS12
12N7-3B	LFX09L2-BS12	YB14A-A1	LFX14A2-BS12
12N7-4A	LFX09A2-BS12	YB14A-A2	LFX14A2-BS12
12N7D-3B	LFX09L2-BS12	YB14-B2	LFX14A2-BS12
12N9-3A	LFX09L2-BS12	YB14L-A1	LFX14L2-BS12
12N9-3B	LFX09L2-BS12	YB14L-A2	LFX14L2-BS12
12N9-4B-1	LFX09A2-BS12	YB14L-B2	LFX14L2-BS12
51814L	LFX18L1-BS12	YB16AL-A2	LFX18L1-BS12
51913L	LFX18L1-BS12	YB16-B	LFX18A1-BS12
53030L	LFX27L3-BS12	YB16B-A	LFX14A1-BS12
6YB11-2D	LFX18L2-BS06	YB16B-A1	LFX14A1-BS12
6YB8L-B	LFX18L2-BS06	YB16-B-CX	LFX18A1-BS12
B38-6A	LFX18L2-BS06	YB16CL-B	LFX18L1-BS12
B54-6	LFX07L2-BS12	YB16HL-A-CX	LFX18L1-BS12
GT14B-4	LFX14A1-BS12	YB16L-B	LFX18L1-BS12
GYZ20HL	LFX24L3-BS12	YB18-A	LFX18A1-BS12
GYZ20L	LFX24L3-BS12	YB18L-A	LFX18L1-BS12
HYB16A-AB	LFX14A1-BS12	YB30CL-B	LFX27L3-BS12
KMX14-BS	LFX14A1-BS12	YB30L-B	LFX27L3-BS12
SY50-N18L-AT	LFX24L3-BS12	YB4L-A	LFX07L2-BS12
SYB14L-A2	LFX14A2-BS12	YB4L-B	LFX07L2-BS12
SYB14L-B2	LFX14A2-BS12	YB5L-B	LFX07L2-BS12
SYB16L-B	LFX18L1-BS12	YB7-A	LFX07A2-BS12
Y50-N18A-A	LFX24A3-BS12	YB7B-B	LFX07A2-BS12
Y50-N18L-A	LFX24L3-BS12	YB7C-A	LFX09L2-BS12
Y50-N18L-A3	LFX24L3-BS12	YB7L-B	LFX09L2-BS12
Y50-N18L-A-CX	LFX24L3-BS12	YB9A-A	LFX09A2-BS12
Y60-N24-A	LFX27A3-BS12	YB9-B	LFX09A2-BS12
YB10A-A2	LFX14A2-BS12	YB9L-A2	LFX09L2-BS12



Battery Cross Reference Chart (Rev. 7-4-2011)

YB9L-B	LFX09L2-BS12	YTZ7S	LFX09L2-BS12
YHD-12H	LFX27A3-BS12	YTZ7S-d	LFX14L2-BS12
YIX30L	LFX27L3-BS12		
YIX30L-BS	LFX27L3-BS12		
YT12A-BS	LFX14A1-BS12		
YT12B-BS	LFX14A1-BS12		
YT14B-BS	LFX14A1-BS12		
YT7B-BS	LFX09A2-BS12		
YT7B-BS-d	LFX14A2-BS12		
YT9B-BS	LFX12A1-BS12		
YTR9-BS	LFX12A1-BS12		
YTX12-BS	LFX14A1-BS12		
YTX14	LFX14A1-BS12		
YTX14AH-BS	LFX14A2-BS12		
YTX14AHL-BS	LFX14L2-BS12		
YTX14-BS	LFX14A1-BS12		
YTX14H	LFX18A1-BS12		
YTX14H-BS	LFX18A1-BS12		
YTX14L	LFX14L1-BS12		
YTX14L-BS	LFX14L1-BS12		
YTX15L-BS	LFX18L1-BS12		
YTX16-BS	LFX18A1-BS12		
YTX16-BS-1	LFX18A1-BS12		
YTX20CH-BS	LFX18A1-BS12		
YTX20H-BS	LFX24A3-BS12		
YTX20HL-BS	LFX24L3-BS12		
YTX20L-BS	LFX24L3-BS12		
YTX24HL-BS	LFX24L3-BS12		
YTX4L-BS	LFX07L2-BS12		
YTX5L-BS	LFX07L2-BS12		
YTX7A-BS	LFX09A2-BS12		
YTX7L-BS	LFX09L2-BS12		
YTX9-BS	LFX12A1-BS12		
YTZ10S	LFX14A2-BS12	-	
YTZ12S	LFX14A1-BS12		
YTZ14S	LFX18A1-BS12		
YTZ5S	LFX07L2-BS12		

"-d" indicates that certain motorcycles which use this OEM battery need the duration equivalent in order to ride smoothly. Check [www.shoraipower.com](http://www.shoraipower.com) year make and model finder to determine if your m/c needs a -d recommendation before purchase.