

13339 NE AIRPORT WAY SUITE 400 PORTLAND, OR 97230 1-866-375-0727

www.speedymoto.com

Installation Instructions

06-0203/06-0204 SpeedyMoto Ducati Clutch Pressure Plate

Parts included

- 1. One very special SpeedyMoto clutch pressure plate
- 2. One very special throw-out bearing (installed)
- 3. One very special SpeedyMoto pushrod pin with o-ring (installed)

Tools required

- 1. 5mm Allen wrench
- 2. 4mm Allen wrench
- 3. Torque wrench

Installation

- 1. Remove right side fairing if applicable.
- 2. Remove clutch cover.(Throw away rubber gasket)

Note

Take note of the positions of the different-length bolts, as they will need to be reinstalled in their original positions.

- 3. Remove the 6 bolts retaining the springs and spring retention caps.
- 4. Gently pull the pressure plate away from clutch assembly, the pushrod may pull out with it, if so simply remove it and re-install it into your new speedymoto pressure plate. (Be sure to put the end with the orings opposite the pressure plate)
- 5. Install your new pressure plate onto clutch assembly, taking care to align the notched hole on the pressure plate with the notched post on the clutch assembly. (Fig. 5)
- 6. While pushing the pressure plate into final position, wiggle the plate until the cogs align and seat.
- 7. Reinstall springs and caps back onto posts. Torque all six bolts to 5 Nm (~3.7 Ft. Lbs.).

Note: BE VERY CAREFUL NOT TO OVER-TORQUE BOLTS.
5Nm is just over finger tight and bolt heads will shear off if they are tightened too much.

- 8. Reinstall clutch cover.
- 9. Replace bodywork if applicable.
- 10. Ride it, and tell all your friends about SpeedyMoto!

