



- 1.) Put the single hole towards the center of the bike and the two holes towards the outside of the bike.
- 2.) Use the longer bolt on the single hole side of the riser.
- 3.) Use the two shorter bolts on the double hole side of the riser.
When looking at the riser on the double hole side
- 4.) Use the non-threaded hole to put a bolt through the bracket and screw it into the handle bar.
- 5.) Place the handle bar (with attached riser) against the top triple clamp.
- 6.) Use the threaded hole to put a bolt from below the top triple clamp, through the clamp, and up into the threaded hole of the riser.
- 7.) Use the longer bolt (included in the hardware) to put through the handlebar, through the riser, and down into the top triple clamp.